



碎纸机使用说明书
SER'S MANUAL

目 录

使用时注意事项

产品

装箱清单

使用说明

保养方法

常见故障分析及排除

.....


.....

.....

.....

.....

.....



入进

产品参数

装箱清单


名称	数量	备注
----	----	----

1

1份

1份

产品外



Useage attention



Caution



Warning

Keep hair away from paper-feeding opening to avoid pulling -in.

※ When accident happens,press "REV" button and th

Product Specifications

340x256x540

Packing List

Shredder	Instruction manual	guarantee card	pass		
		1			




Maintenance

1. Pull out the power plug from the socket of power supply before maintenance
2. The maintenance by user is only limited to cleaning visible surface of the shredder.
3. When cleaning the surface of the shredder, do not allow water to drop into the interior of the shredder.

Trouble Analysis & Trouble Shooting

	TROUBLE ANALYSIS	TROUBLESHOOTING
	plug disconnect, no power	



DELLER

全国联保，